



CRYE PRECISION™

STOCKPAD™

FOR AIRFRAME™ CHOPS

RIGHT SIDE

INCLUDES ONE STOCKPAD™ AND ONE ALCOHOL PREP PAD

INSTRUCTIONS

- 1.** Use the included alcohol prep pad to wipe and clean the application area. Allow area to fully dry.
- 2.** Remove clear backing from StockPad™ and stick to the Chop as shown below. Press firmly and evenly over entire area to ensure proper adhesion and to avoid any air bubbles.

