



# AIRFRAME™ PELTOR® ADAPTER SET



# INSTALLATION INSTRUCTIONS



1. Unmount device from helmet. Disassemble mount by unscrewing phillips head screw. Remove rear plastic portion.



2. Replace rear plastic part with AirFrame™ Peltor® Adapter and replace screw. Repeat for other side.



3. Slide onto AirFrame™ Rail from either direction into desired position.