



JUMPABLE PLATE CARRIER™ (JPC)

E-DOFF KIT INSTALLATION INSTRUCTIONS



1 Separate front carrier from rear carrier by detaching the shoulder straps. Remove stretch shoulder sleeves from shoulder straps. Front carrier left shoulder strap shown.



2 Mate shoulder quick-release tab on top side of front carrier shoulder strap as shown. The quick-release tab can be positioned farther down shoulder strap (closer to platebag) if higher ride height is required.



3 Fold shoulder strap and quick-release tab back over itself.



4 Pull quick-release toggle through opening in shoulder strap as shown to complete front carrier quick-release assembly.



5 Attach e-doff shoulder cover to rear carrier left shoulder strap by mating loop tab of e-doff shoulder cover to bottom edge of rear left shoulder strap hook panel.



6 Correct mating of e-doff shoulder cover and rear carrier left shoulder strap shown.



7 Place front carrier quick-release assembly onto rear carrier e-doff shoulder cover as shown.



8 Correct placement of front and rear carrier shoulder straps with quick-release tab and e-doff shoulder cover shown.



9 Close e-doff shoulder cover as shown.



10 Mate cummerbund quick-release tab diagonally on the back side (hook portion) of cummerbund as shown. The toggle end of the quick-release tab should lay towards the top corner of the cummerbund.



11 Fold toggle end of cummerbund quick-release tab over the corner of the cummerbund and attach to the front loop panel.



12 Completed assembly of cummerbund quick-release tab shown. The cummerbund and quick-release tab will be placed under JPC™ front carrier flap as shown.

EMERGENCY DOFFING PROCEDURE



1 To release shoulder, pull on shoulder quick-release tab. Shoulder strap will be pulled through opening in shoulder strap.



2 To release cummerbund, pull on cummerbund quick-release tab. Cummerbund will pull out from under front carrier flap.



3 JPC™ shown after emergency doffing procedure.