



**CRYE PRECISION**

**5.56 / 7.62 / MBITR POUCH**




P/N: SPS-067


© CRYE PRECISION LLC. ALL RIGHTS RESERVED.  
MADE IN THE U.S. FROM U.S. MATERIALS  
[WWW.CRYEPRECISION.COM](http://WWW.CRYEPRECISION.COM)

# INSTALLATION INSTRUCTIONS


## MOLLE ATTACHMENT



1 Pass end of attaching strap tabs through top row of PALS on platform.




2 Extend attaching straps so pouch is pulled tight against platform, pass attaching strap tabs through top bar on pouch, continue weaving until last row of PALS in engaged.




3 Pass attaching strap tabs through bottom bar on pouch, fold tab back on itself and tuck behind bottom PALS row.


## AVS™ HARNESS ARM ATTACHMENT




1 Locate AVS™ Arm sleeve on back of pouch, separate Velcro.




2 Pass the AVS™ Arm through the sleeve on the back of the pouch.




3 Place in desired location, press  of AVS™ Arm to secure in place.


## BELT MOUNT



1 Secure attaching strap tabs through the webbing on the back of the pouch.



2 Locate belt sleeve on the back of the pouch.



3 Pass belt through sleeve and slide to desired location.