



CRYE PRECISION

FRAG POUCH MARITIME



P/N: MPS-013
© CRYE PRECISION LLC. ALL RIGHTS RESERVED.
MADE IN THE U.S. FROM U.S. MATERIALS
WWW.CRYEPRECISION.COM

INSTALLATION INSTRUCTIONS

MOLLE ATTACHMENT



- 1 Pass end of attaching strap tabs through top row of PALS on platform.



- 2 Extend attaching straps so pouch is pulled tight against platform, pass attaching strap tabs through top bar on pouch, continue weaving until last row of PALS in engaged.



- 3 Pass attaching strap tabs through bottom bar on pouch, fold tab back on itself and tuck behind bottom PALS row.